HUAWEI U8150 V100R001C253B836 Software Upgrade Guideline

Prepared by	U8150 TEAM	Date	2011-01-20

Huawei Technologies Co., Ltd.

All rights reserved

Contents

1 VERSION INTRODUCTION 3

1.1 THE FOLLOWING VERSIONS CAN BE UPGRADED. 3

1.2 UPGRADE PREREQUISITE 3

1.3 UPGRADE FILES 3

2 UPGRADE PREPARATION 3

2.1 CHECK CURRENT UPGRADE ENVIRONMENT 3

2.2 GET AND CHECK THE SOFTWARE PACKAGE 3

3 UPGRADE OPERATIONS 4

3.1 MAIN PACKAGE UPGRADE 4

4 UPGRADE VALIDATE 5

4.1 CHECK THE VERSION 5

4.2 BASIC FUNCTION CHECK 6

5 NOTES 6

5.1 NOTES 6

1 Version introduction

1.1 The following versions can be upgraded.

Versions can be upgraded
HUAWEI U8150 V100R001C253B836

1.2 Upgrade prerequisite

The U8150 handset software should be updated with the MICRO SD card.

1.3 Upgrade files

	File Name
Software: main package	U8150V100R001C253B836.rar
Update tools	SD card

2 Upgrade preparation

2.1 Check current upgrade environment

SD card update: Make sure that the MICRO SD card is available and can be read and write.

2.2 Get and check the software package

Note:

1. There is 1 SD card upgrade packages: one main package.

2. Copy the dload folder to SD card, after copying, the directory is /sdcard/dload/

3 Upgrade operations

Notes:

1: Upgrade operations will erase the user data.

2: To make sure that the power of the battery is enough to run the upgrade process.(We recommend the battery is full.)

3.1 Main package upgrade

Step 1. A MICRO SD card of 256MB or more should be available. The MICRO SD card made by Sandisk, Kingstone, or Kingmax is recommended.

Step 2. Format the MICRO SD card (This operation is optional).

Step 3. Unzip the customized package U8150V100R001C253B836.rar (right click your mouse and select 'Extract here').

Step 4. Obtain the unzipped file (subdirectory: \dload*.*) to be upgraded

Step 5. Copy the entire dload folder (with UPDATE.APP in it) to the root directory of the MICRO SD card.

Step 6. Make sure your handset is power off. Insert the MICRO SD card into the handset. Pressing the END key and VOLUME UP key, and then press the POWER key to power on the phone and enter the Software Upgrade Mode.

Step 7. You can see process bar start from 0 on the screen. Please see below pictures.

Step 1 Step 2 Step 3

Step 8. Then the handset will restart automatically. Then it is OK.

Note: The battery should have the enough power in the upgrading progress.

4 Upgrade validate

4.1 Check the version

1. By Setting ->About phone, to check the version like the



U8150V100R001C253B836

4.2 Basic function check

Switch on the handset, enter the idle screen, input a dial number and make a voice call, then long press the power key to power off the handset.

5 Notes

5.1 Notes

1. To make sure that the power of the battery is enough to run the upgrade process. Maybe you can connect the handset with the charger or the USB data cable to provide power.
2. If your current version is older than CXXB808(include)，you need to update a transfer package before updating the main package. Please do not update the software by yourself, you need contact the research and development center.
3. If your current version is between CXXB808 and CXXB812(include), please modify the file ‘s name UPDATE.APP to UPDATA.APP first, then update the software. And you will find below picture displayed in the screen of your phone when updating the main package, please do the update again following Chapter 3.1 Step 6-Step 8.



4. If your current version is between CXXB812 and CXXB819, you will find below picture displayed in the screen of your phone when updating the main package, please do the update again following Chapter 3.1 Step 6- Step 8.


Update failed